

## HANSON FONG'S SKIN GLOW BOUNCE CARD

There are two sides to the Skin Glow, natural side and warm side. The Natural (White) side is used for indoor or outdoor photography. The Warm (pink) side is used mainly for outdoor photography. It is used to tone down the blues and greens, which will eventually “warm up” your photographs. This is similar to a sky light filter.

The kit comes with 3 pieces of Velcro, 2- 2” squared and 1- 11”-12” Velcro strap. Place the 2” Velcro on each side of your strobe. Because the Skin Glow is already mounted with Velcro, by placing the Velcro square on each side of your strobe, you can easily mount the Skin Glow. The key part of the Skin Glow is the hinge, which can either tilt back or forward, depending on your needs.

The Skin Glow has a hinge, which assists you in controlling the amount of “bounce” you would prefer. A strap has been provided to control the “bounce” from the Skin Glow. You should Velcro the Skin Glow (hinge level) slightly ( $\sim 1/3$ ”) below the edge of your strobe. Tilt the Skin Glow at the desired tilt and secure it with the strap around the strobe.

Another piece of advice is to place the Skin Glow hinge at different levels from the edge of strobe. By doing so, you will be able to maximize the use of Skin Glow.